

Groundwater complement or active groundwater level management



Groundwater levels can be (temporarily) increased in some cases. This does require the adaptation of buildings. An increase in groundwater level can only be done if this does not lead to damage. For instance, buildings should be water resistant or be placed on a higher groundlevel.

